



Information for the operator of the machine

# 9300 *0.37 ... 11 kW*



**EVS9321-xx ... EVS9326-xx**

**Servo controller**



## Key for overview

Position	Description
A	Controller
B	Fixing rails for standard mounting
C	Cover for the motor connection
D	Shield connection support with fixing screws (2 items) 1 support for the shield sheet for the supply connections 1 support for the shield sheet for the motor cable
E	EMC shield sheet with fixing screws (2 items) 1 shield sheet for the supply connections 1 shield sheet for the motor cable and the feed cable for the motor temperature monitoring with PTC thermistor or thermal contact (NC contact)
F	EMC shield sheet with fixing screws for shielded control cables
G	Cover for the supply connections

## Connections and interfaces

Position	Description
L1, L2, L3, PE	Mains connection
+UG, -UG	DC supply
U, V, W, PE	Motor connection
T1, T2	Connection of PTC thermistor or thermal contact (NC contact) of the motor
X1	AIF interface (automation interface) Slot for communication module (e. g. XT EMZ9371BC keypad)
X3	Jumper for setting analog input signal at X6/1, X6/2
X4	System bus (CAN) connection
X5	Connection of digital inputs and outputs
X6	Connection of analog inputs and outputs
X7	Connection of resolver and KTY temperature sensor of the motor
X8	Connection of incremental encoder with TTL level or SinCos encoder and KTY temperature sensor of the motor
X9	Connection of digital frequency input signal
X10	Connection of digital frequency output signal
X11	Connection of K <sub>SR</sub> relay output for "safe standstill" (for variants V004 and V104 only)

## Status displays

Position	LED red	LED green	Operating status
①	Off	On	Controller enabled
	On	On	Mains is switched on and automatic start is inhibited
	Off	Blinking slowly	Controller inhibited
	Blinking quickly	Off	Undervoltage or overvoltage
	Blinking slowly	Off	Active fault

<b>1</b>	<b>About this documentation</b> .....	<b>5</b>
1.1	Document history .....	5
1.2	Target group .....	5
1.3	Validity information .....	6
1.4	Conventions used .....	7
1.5	Notes used .....	8
<b>2</b>	<b>Safety instructions</b> .....	<b>9</b>
2.1	General safety and application notes for Lenze controllers .....	9
2.2	Thermal motor monitoring .....	13
2.2.1	Forced ventilated or naturally ventilated motors .....	14
2.2.2	Self-ventilated motors .....	15
2.3	Residual hazards .....	17
2.4	Safety instructions for the installation according to UL .....	18
<b>3</b>	<b>Parameter setting</b> .....	<b>19</b>
3.1	Parameter setting with the XT EMZ9371BC keypad .....	19
3.1.1	General data and operating conditions .....	19
3.1.2	Installation and commissioning .....	20
3.1.3	Display elements and function keys .....	21
3.1.4	Changing and saving parameters .....	23
3.1.5	Loading a parameter set .....	25
3.1.6	Transferring parameters to other standard devices .....	26
3.1.7	Activating password protection .....	28
3.1.8	Diagnostics .....	29
3.1.9	Menu structure .....	30
<b>4</b>	<b>Troubleshooting and fault elimination</b> .....	<b>32</b>
4.1	Display of operating data, diagnostics .....	32
4.2	Troubleshooting .....	33
4.2.1	Status display via controller LEDs .....	33
4.2.2	Fault analysis with the history buffer .....	34
4.2.3	Fault analysis via LECOM status words (C0150/C0155) .....	35
4.3	System error messages .....	36
4.3.1	General error messages .....	36
4.3.2	Resetting system error messages .....	45

# 1 About this documentation



## Note!

This documentation contains all necessary information for the machine operator to be able to operate the servo controllers of the 9300 series installed in your machine/plant.

You can make further use of all information in this documentation without consulting Lenze if you do not make any changes to the contents.

## 1.1 Document history

### What is new / what has changed?

Material number	Version			Description
13440647	3.0	07/2013	TD06	Error corrections
13330541	2.1	03/2010	TD23	Change of the company's address
13330541	2.0	03/2010	TD14	New edition due to reorganisation of the company UL-warnings updated Revision for software version 8x
13231631	1.0	11/2007	TD34	First edition



## Tip!

Information and auxiliary devices related to the Lenze products can be found in the download area at

<http://www.Lenze.com>

## 1.2 Target group

This documentation is directed at qualified skilled personnel according to IEC 60364.

Qualified skilled personnel are persons who have the required qualifications to carry out all activities involved in installing, mounting, commissioning, and operating the product.


# 1 About this documentation

## Validity information

### 1.3 Validity information







... 9300 servo controllers as of nameplate data:

	①	②	③	Nameplate																					
	EVS	93xx	- x x	Vxxx 1x 8x																					
<b>Product series</b>	EVS = Servo controller																								
<b>Type no. / rated power</b>	<table border="1"> <thead> <tr> <th></th> <th>400 V</th> <th>480 V</th> </tr> </thead> <tbody> <tr> <td>9321 =</td> <td>0.37 kW</td> <td>0.37 kW</td> </tr> <tr> <td>9322 =</td> <td>0.75 kW</td> <td>0.75 kW</td> </tr> <tr> <td>9323 =</td> <td>1.5 kW</td> <td>1.5 kW</td> </tr> <tr> <td>9324 =</td> <td>3.0 kW</td> <td>3.0 kW</td> </tr> <tr> <td>9325 =</td> <td>5.5 kW</td> <td>5.5 kW</td> </tr> <tr> <td>9326 =</td> <td>11 kW</td> <td>11 kW</td> </tr> </tbody> </table>					400 V	480 V	9321 =	0.37 kW	0.37 kW	9322 =	0.75 kW	0.75 kW	9323 =	1.5 kW	1.5 kW	9324 =	3.0 kW	3.0 kW	9325 =	5.5 kW	5.5 kW	9326 =	11 kW	11 kW
	400 V	480 V																							
9321 =	0.37 kW	0.37 kW																							
9322 =	0.75 kW	0.75 kW																							
9323 =	1.5 kW	1.5 kW																							
9324 =	3.0 kW	3.0 kW																							
9325 =	5.5 kW	5.5 kW																							
9326 =	11 kW	11 kW																							
<b>Type</b>	E = Panel-mounted unit C = Built-in unit in "cold plate" technique																								
<b>Design</b>	I = Servo PLC K = Servo cam P = Servo position controller R = Register controller S = Servo inverter T = Servo PLC technology																								
<b>Variant</b>	- Standard V003 = In "cold plate" technique V004 = With "safe standstill" function V100 = For IT mains V104 = With "safe standstill" function and for IT mains																								
<b>Hardware version</b>																									
<b>Software version</b>																									



## 1.4 Conventions used

This documentation uses the following conventions to distinguish between different types of information:

Type of information	Identification	Examples/notes
Spelling of numbers		
Decimal separator	language-dependent	In each case, the signs typical for the target language are used as decimal separators. For example: 1234.56 or 1234,56
Warnings		
UL warnings		Are only given in English.
UR warnings		
Text		
Program name	» «	PC software For example: »Engineer«, »Global Drive Control« (GDC)
Icons		
Page reference		Reference to another page with additional information For instance:  16 = see page 16
Documentation reference		Reference to another documentation with additional information For example:  EDKxxx = see documentation EDKxxx

# 1 About this documentation

Notes used

## 1.5 Notes used

The following pictographs and signal words are used in this documentation to indicate dangers and important information:

### Safety instructions

Structure of safety instructions:






#### **Danger!**




(characterises the type and severity of danger)

#### **Note**



(describes the danger and gives information about how to prevent dangerous situations)

Pictograph and signal word	Meaning
 <b>Danger!</b>	<b>Danger of personal injury through dangerous electrical voltage.</b> Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
 <b>Danger!</b>	<b>Danger of personal injury through a general source of danger.</b> Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
 <b>Stop!</b>	<b>Danger of property damage.</b> Reference to a possible danger that may result in property damage if the corresponding measures are not taken.

### Application notes

Pictograph and signal word	Meaning
 <b>Note!</b>	Important note to ensure troublefree operation
 <b>Tip!</b>	Useful tip for simple handling
	Reference to another documentation

### Special safety instructions and application notes for UL and UR

Pictograph and signal word	Meaning
 <b>Warnings!</b>	<b>Safety or application note for the operation of a UL-approved device in UL-approved systems.</b> Possibly the drive system is not operated in compliance with UL if the corresponding measures are not taken.
 <b>Warnings!</b>	<b>Safety or application note for the operation of a UR-approved device in UL-approved systems.</b> Possibly the drive system is not operated in compliance with UL if the corresponding measures are not taken.



## 2 Safety instructions

### 2.1 General safety and application notes for Lenze controllers

(in accordance with Low-Voltage Directive 2006/95/EC)

#### For your personal safety

Disregarding the following safety measures can lead to severe injury to persons and damage to material assets:

- ▶ Only use the product as directed.
- ▶ Never commission the product in the event of visible damage.
- ▶ Never commission the product before assembly has been completed.
- ▶ Do not carry out any technical changes on the product.
- ▶ Only use the accessories approved for the product.
- ▶ Only use original spare parts from Lenze.
- ▶ Observe all regulations for the prevention of accidents, directives and laws applicable on site.
- ▶ Transport, installation, commissioning and maintenance work must only be carried out by qualified personnel.
  - Observe IEC 364 and CENELEC HD 384 or DIN VDE 0100 and IEC report 664 or DIN VDE 0110 and all national regulations for the prevention of accidents.
  - According to this basic safety information, qualified, skilled personnel are persons who are familiar with the assembly, installation, commissioning, and operation of the product and who have the qualifications necessary for their occupation.
- ▶ Observe all specifications in this documentation.
  - This is the condition for safe and trouble-free operation and the achievement of the specified product features.
  - The procedural notes and circuit details described in this documentation are only proposals. It is up to the user to check whether they can be transferred to the particular applications. Lenze Automation GmbH does not accept any liability for the suitability of the procedures and circuit proposals described.
- ▶ Depending on their degree of protection, some parts of the Lenze controllers (frequency inverters, servo inverters, DC speed controllers) and their accessory components can be live, moving and rotating during operation. Surfaces can be hot.
  - Non-authorized removal of the required cover, inappropriate use, incorrect installation or operation, creates the risk of severe injury to persons or damage to material assets.
  - For more information, please see the documentation.
- ▶ High amounts of energy are produced in the controller. Therefore it is required to wear personal protective equipment (body protection, headgear, eye protection, ear protection, hand guard).

**Application as directed**

Controllers are components which are designed for installation in electrical systems or machines. They are not to be used as domestic appliances, but only for industrial purposes according to EN 61000-3-2.

When controllers are installed into machines, commissioning (i.e. starting of the operation as directed) is prohibited until it is proven that the machine complies with the regulations of the EC Directive 2006/42/EC (Machinery Directive); EN 60204 must be observed.

Commissioning (i.e. starting of the operation as directed) is only allowed when there is compliance with the EMC Directive (2004/108/EC).

The controllers meet the requirements of the Low-Voltage Directive 2006/95/EC. The harmonised standard EN 61800-5-1 applies to the controllers.

The technical data and supply conditions can be obtained from the nameplate and the documentation. They must be strictly observed.

**Warning:** Controllers are products which can be installed in drive systems of category C2 according to EN 61800-3. These products can cause radio interferences in residential areas. In this case, special measures can be necessary.

**Transport, storage**

Please observe the notes on transport, storage, and appropriate handling.

Observe the climatic conditions according to the technical data.

**Installation**

The controllers must be installed and cooled according to the instructions given in the corresponding documentation.

The ambient air must not exceed degree of pollution 2 according to EN 61800-5-1.

Ensure proper handling and avoid excessive mechanical stress. Do not bend any components and do not change any insulation distances during transport or handling. Do not touch any electronic components and contacts.

Controllers contain electrostatic sensitive devices which can easily be damaged by inappropriate handling. Do not damage or destroy any electrical components since this might endanger your health!

### Electrical connection

When working on live controllers, observe the applicable national regulations for the prevention of accidents (e.g. VBG 4).

The electrical installation must be carried out according to the appropriate regulations (e.g. cable cross-sections, fuses, PE connection). Additional information can be obtained from the documentation.

This documentation contains information on installation in compliance with EMC (shielding, earthing, filter, and cables). These notes must also be observed for CE-marked controllers. The manufacturer of the system is responsible for compliance with the limit values demanded by EMC legislation. The controllers must be installed in housings (e.g. control cabinets) to meet the limit values for radio interferences valid at the site of installation. The housings must enable an EMC-compliant installation. Observe in particular that e.g. the control cabinet doors have a circumferential metal connection to the housing. Reduce housing openings and cutouts to a minimum.

Lenze controllers may cause a DC current in the PE conductor. If a residual current device (RCD) is used for protection against direct or indirect contact for a controller with three-phase supply, only a residual current device (RCD) of type B is permissible on the supply side of the controller. If the controller has a single-phase supply, a residual current device (RCD) of type A is also permissible. Apart from using a residual current device (RCD), other protective measures can be taken as well, e.g. electrical isolation by double or reinforced insulation or isolation from the supply system by means of a transformer.

### Operation

If necessary, systems including controllers must be equipped with additional monitoring and protection devices according to the valid safety regulations (e.g. law on technical equipment, regulations for the prevention of accidents). The controllers can be adapted to your application. Please observe the corresponding information given in the documentation.

After the controller has been disconnected from the supply voltage, all live components and power terminals must not be touched immediately because capacitors can still be charged. Please observe the corresponding stickers on the controller.

All protection covers and doors must be shut during operation.

**Notes for UL-approved systems with integrated controllers:** UL warnings are notes that only apply to UL systems. The documentation contains special UL notes.

### Safety functions

Certain controller versions support safety functions (e.g. "Safe torque off", formerly "Safe standstill") according to the requirements of the EC Directive 2006/42/EC (Machinery Directive). The notes on the integrated safety system provided in this documentation must be observed.

### Maintenance and servicing

The controllers do not require any maintenance if the prescribed operating conditions are observed.

**Disposal**

Recycle metal and plastic materials. Ensure professional disposal of assembled PCBs.

**The product-specific safety and application notes given in these instructions must be observed!**

## 2.2 Thermal motor monitoring

From software version 8.0 onwards, the 9300 controllers are provided with an  $I^2t$  function for sensorless thermal monitoring of the connected motor.



### Note!

- ▶  $I^2t$  monitoring is based on a mathematical model which calculates a thermal motor load from the detected motor currents.
- ▶ The calculated motor load is saved when the mains is switched.
- ▶ The function is UL-certified, i.e. no additional protective measures are required for the motor in UL-approved systems.
- ▶ However,  $I^2t$  monitoring is **no** full motor protection as other influences on the motor load could not be detected as for instance changed cooling conditions (e.g. interrupted or too warm cooling air flow).

The  $I^2t$  load of the motor is displayed in C0066.

The thermal loading capacity of the motor is expressed by the thermal motor time constant ( $\tau$ , C0128). Find the value in the rated motor data or contact the manufacturer of the motor.

The  $I^2t$  monitoring has been designed such that it will be activated after 179 s in the event of a motor with a thermal motor time constant of 5 minutes (Lenze setting C0128), a motor current of  $1.5 \times I_N$  and a trigger threshold of 100 %.

Two adjustable trigger thresholds provide for different responses.

- ▶ Adjustable response OC8 (TRIP, warning, off).
  - The trigger threshold is set in C0127.
  - The response is set in C0606.
  - The response OC8, for instance, can be used for an advance warning.
- ▶ Fixed response OC6-TRIP.
  - The trigger threshold is set in C0120.

Behaviour of the $I^2t$ monitoring	Condition
The $I^2t$ monitoring is deactivated. C0066 is set = 0 % and MCTRL-LOAD-I2XT is set = 0.00 %.	When C0120 = 0 % and C0127 = 0 %, set controller inhibit.
$I^2t$ monitoring is stopped. The current value in C0066 and at the MCTRL-LOAD-I2XT output is frozen.	When C0120 = 0 % and C0127 = 0 %, set controller enable.
$I^2t$ monitoring is deactivated. The motor load is displayed in C0066.	Set C0606 = 3 (off) and C0127 > 0 %.



### Note!

An error message OC6 or OC8 can only be reset if the  $I^2t$  load falls below the set trigger threshold by 5 %.

## 2.2.1 Forced ventilated or naturally ventilated motors

## Parameter setting

The following codes can be set for I<sup>2</sup> x t monitoring:

Code	Meaning	Value range	Lenze setting
C0066	Display of the I <sup>2</sup> x t load of the motor	0 ... 250 %	-
C0120	Threshold: Triggering of error "OC6"	0 ... 120 %	0 %
C0127	Threshold: Triggering of error "OC8"	0 ... 120 %	0 %
C0128	Thermal motor time constant	0.1 ... 50.0 min	5.0 min
C0606	Response to error "OC8"	TRIP, warning, off	Warning

Calculate release time and I<sup>2</sup> x t load

Formula for release time	Information
$t = -(\tau) \times \ln \left[ 1 - \frac{z + 1}{\left(\frac{I_{Mot}}{I_N}\right)^2 \times 100} \right]$	I <sub>Mot</sub> Actual motor current (C0054)
	I <sub>r</sub> Rated motor current (C0088)
	τ Thermal motor time constant (C0128)
	z Threshold value in C0120 (OC6) or C0127 (OC8)

Formulae for I <sup>2</sup> x t load	Information
$L(t) = \left(\frac{I_{Mot}}{I_N}\right)^2 \times 100\% \times \left(1 - e^{-\frac{t}{\tau}}\right)$	L(t) Chronological sequence of the I <sup>2</sup> x t load of the motor (Display: C0066)
	I <sub>Mot</sub> Actual motor current (C0054)
	I <sub>r</sub> Rated motor current (C0088)
	τ Thermal motor time constant (C0128)

If the controller is inhibited, the I<sup>2</sup> x t load is reduced:

$L(t) = L_{Start} \times \sqrt{e^{-\frac{t}{\tau}}}$	L <sub>Start</sub> I <sup>2</sup> x t load before controller inhibit If an error is triggered, the value corresponds to the threshold value set in C0120 (OC6) or C0127 (OC8).
--	---

## Read release time in the diagram

Diagram for detecting the release times for a motor with a thermal motor time constant of 5 minutes (Lenze setting C0128):




Fig. 2-1 I<sup>2</sup> x t-monitoring: Release times for different motor currents and trigger thresholds

I <sub>Mot</sub>	Actual motor current (C0054)
I <sub>r</sub>	Rated motor current (C0088)
L	I <sup>2</sup> x t load of the motor (display: C0066)
T	Time

## 2.2.2 Self-ventilated motors

Due to the construction, self-ventilated standard motors are exposed to an increased heat generation in the lower speed range compared to forced ventilated motors.



### Warnings!

For complying with the UL 508C standard, you have to set the speed-dependent evaluation of the permissible torque via code **C0129/x**.

### Parameter setting

The following codes can be set for  $I^2 \times t$  monitoring:

Code	Meaning	Value range	Lenze setting
C0066	Display of the $I^2 \times t$ load of the motor	0 ... 250 %	-
C0120	Threshold: Triggering of error "OC6"	0 ... 120 %	0 %
C0127	Threshold: Triggering of error "OC8"	0 ... 120 %	0 %
C0128	Thermal motor time constant	0.1 ... 50.0 min	5.0 min
C0606	Response to error "OC8"	TRIP, warning, off	Warning
C0129/1	S1 torque characteristic $I_1/I_{rated}$	10 ... 200 %	100 %
C0129/2	S1 torque characteristics $n_2/n_{rated}$	10 ... 200 %	40 %

### Effect of code C0129/x




Fig. 2-2 Working point in the range of characteristic lowering

The lowered speed / torque characteristic (Fig. 2-2) reduces the permissible thermal load of self-ventilated standard motors. The characteristic is a line the definition of which requires two points:

- ▶ Point **A**: Definition with **C0129/1**  
This value also enables an increase of the maximally permissible load.
- ▶ Point **B**: Definition with **C0129/2**  
With increasing speeds, the maximally permissible load remains unchanged ( $I_{Mot} = I_{rated}$ ).

In Fig. 2-2, the motor speed and the corresponding permissible motor torque (**D**) can be read for each working point (**C** on the characteristic (**A**) ... **B**). **D** can also be calculated using the values in **C0129/1** and **C0129/2** (evaluation coefficient "y", [16](#)).

## Safety instructions

Thermal motor monitoring  
Self-ventilated motors

### Calculate release time and I<sup>2</sup> x t load

Calculate the release time and the I<sup>2</sup> x t load of the motor considering the values in **C0129/1** and **C0129/2** (evaluation coefficient "y").

Formulae for release time	Information
$T = -(\tau) \times \ln \left[ 1 - \frac{z + 1}{\left( \frac{I_{Mot}}{y \times I_N} \right)^2 \times 100} \right]$ $y = \frac{100\% - C0129/1}{C0129/2} \times \frac{n}{n_N} + C0129/1$	T
	Release time of the I <sup>2</sup> x t monitoring
	τ
	Thermal motor time constant (C0128)
	ln
	Function: Natural logarithm
	I <sub>Mot</sub>
	Actual motor current (C0054)
	I <sub>r</sub>
	Rated motor current (C0088)
	z
	Threshold value in C0120 (OC6) or C0127 (OC8)
	y
	Evaluation coefficient
	n <sub>rated</sub>
	Rated speed (C0087)
Formulae for I <sup>2</sup> x t load	Information
$L(t) = \left( \frac{I_{Mot}}{y \times I_N} \right)^2 \times 100\% \times \left( 1 - e^{-\frac{t}{\tau}} \right)$	L(t)
	Chronological sequence of the I <sup>2</sup> x t load of the motor (Display: C0066)
	y
	Evaluation coefficient
	I <sub>Mot</sub>
	Actual motor current (C0054)
	I <sub>r</sub>
	Rated motor current (C0088)
	τ
	Thermal motor time constant (C0128)
If the controller is inhibited, the I <sup>2</sup> x t load is reduced:	
$L(t) = L_{start} \times \sqrt{e^{-\frac{t}{\tau}}}$	L <sub>start</sub>
	I <sup>2</sup> x t load before controller inhibit If an error is triggered, the value corresponds to the threshold value set in C0120 (OC6) or C0127 (OC8).



## 2.3 Residual hazards

### Protection of persons

- ▶ Before working on the controller, check whether all power terminals are deenergised:
  - The power terminals U, V, W, +U<sub>G</sub> and -U<sub>G</sub> remain live for at least three minutes after disconnection from the mains.
  - The power terminals L1, L2, L3; U, V, W, +U<sub>G</sub> and -U<sub>G</sub> remain live when the motor is stopped.
- ▶ The leakage current to earth (PE) is > 3.5 mA. According to EN 61800-5-1
  - a fixed installation is required.
  - a double PE connection is required or, if in single design, it must have a cable cross-section of at least 10 mm<sup>2</sup>.
- ▶ The heatsink of the controller has an operating temperature of > 80 °C:
  - Contact with the heatsink results in burns.
- ▶ During parameter set transfer the control terminals of the controller can have undefined states.
  - Therefore the connectors X5 and X6 must be disconnected from the controller before the transfer takes place. This ensures that the controller is inhibited and all control terminals have the defined state "LOW".

### Device protection

- ▶ Frequent mains switching (e.g. inching mode via mains contactor) can overload and destroy the input current limitation of the drive controller:
  - At least 3 minutes must pass between switching off and restarting the devices EVS9321-xx and EVS9322-xx.
  - At least 3 minutes must pass between two starting procedures of the devices EVS9323-xx ... EVS9332-xx.
  - Use the "safe torque off" safety function (STO) if safety-related mains disconnections occur frequently. The drive variants Vxx4 are equipped with this function.

### Protection of the machine/system

- ▶ Drives can reach dangerous overspeeds (e. g. setting of high output frequencies in connection with motors and machines not suitable for this purpose):
  - The drive controllers do not provide protection against such operating conditions. For this purpose, use additional components.

**Warnings!**

- ▶ **Motor Overload Protection**
  - For information on the protection level of the internal overload protection for a motor load, see the corresponding manuals or software helps.
  - If the integral solid state motor overload protection is not used, external or remote overload protection must be provided.
- ▶ **Branch Circuit Protection**
  - The integral solid state protection does not provide branch circuit protection.
  - Branch circuit protection has to be provided externally in accordance with corresponding instructions, the National Electrical Code and any additional codes.
- ▶ Please observe the specifications for fuses and screw-tightening torques in these instructions.
- ▶ **EVS9321 ... EVS9326:**
  - Suitable for use on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 480 V maximum, when protected by fuses.
  - Suitable for use on a circuit capable of delivering not more than 50000 rms symmetrical amperes, 480 V maximum, when protected by CC, J, T or R class fuses.
  - Maximum surrounding air temperature: 0 ... +55 °C
  - > +40 °C: reduce the rated output current by 2.5 %/°C
  - Use 75 °C copper wire only.

### 3 Parameter setting

#### 3.1 Parameter setting with the XT EMZ9371BC keypad

##### Description


The keypad is available as an accessory. A full description of the keypad can be obtained from the Instructions included in the keypad delivery.

##### Plugging in the keypad

It is possible to plug the keypad into the AIF interface or remove it during operation.

As soon as the keypad is supplied with voltage, it carries out a self-test. The keypad is ready for operation if it is in display mode.

#### 3.1.1 General data and operating conditions



Feature	Values	
<b>Dimensions</b>		
Width	a	60 mm
Height	b	73.5 mm
Depth	c	15 mm
<b>Environmental conditions</b>		
Climate		
Storage	IEC/EN 60721-3-1	1K3 (-25 ... +60 °C)
Transport	IEC/EN 60721-3-2	2K3 (-25 ... +70 °C)
Operation	IEC/EN 60721-3-3	3K3 (-10 ... +60 °C)
Enclosure	IP 20	

## 3.1.2

## Installation and commissioning




Fig. 3-1 Installation and commissioning of XT EMZ9371BC keypad or E82ZBBXC diagnosis terminal

- ① Connect keypad to the AIF interface on the front of the standard device.  
The keypad can be connected/disconnected during operation.
- ② As soon as the keypad is supplied with voltage, it carries out a short self-test.
- ③ The operation level indicates when the keypad is ready for operation:
  - Ⓐ Current state of the standard device
  - Ⓑ Memory location 1 of the user menu (C0517):  
Code number, subcode number, and current value
  - Ⓒ Active fault message or additional status message
  - Ⓓ Actual value in % of the status display defined in C0004
- ④ **PRG** must be pressed to leave the operation level

3.1.3 Display elements and function keys




Fig. 3-2 Display elements and function keys of the XT EMZ9371BC keypad

Displays

A Status displays of standard device		
Display	Meaning	Explanation
RDY	Ready for operation	
IMP	Pulse inhibit is active	Power outputs are inhibited
I <sub>max</sub>	The set current limit is exceeded in motor or generator mode	
M <sub>max</sub>	Speed controller 1 in the limitation	Drive is torque-controlled (Only active for operation with standard devices of the 9300 series)
Fail	Active fault	
B Acceptance of the parameters		
Display	Meaning	Explanation
↔	Parameter is accepted immediately	Standard device operates immediately with the new parameter value
SHPRG ↔	Parameter must be acknowledged with <b>SHIFT PRG</b>	Standard device operates with the new parameter value after being acknowledged
SHPRG	Parameter must be acknowledged in case of controller inhibit <b>SHIFT PRG</b>	Standard device operates with the new parameter value after the controller is enabled again
None	Display parameter	Change is not possible
C Active level		
Display	Meaning	Explanation
Menu	Menu level is active	Select main menu and submenus
Code	Code level is active	Select codes and subcodes
Para	Parameter level is active	Change parameters in the codes or subcodes
None	Operating level is active	Display operating parameters
D Short text		
Display	Meaning	Explanation
alphanumeric	Contents of the menus, meaning of the codes and parameters	
	In the operating level display of C0004 in % and the active fault	

## Parameter setting

Parameter setting with the XT EMZ9371BC keypad  
Display elements and function keys

<b>E</b>	<b>Number</b>		
	<b>Active level</b>	<b>Meaning</b>	<b>Explanation</b>
	Menu level	Menu number	Display is only active for operation with standard devices of the 8200 vector or 8200 motec series
	Code level	Four-digit code number	
<b>F</b>	<b>Number</b>		
	<b>Active level</b>	<b>Meaning</b>	<b>Explanation</b>
	Menu level	Submenu number	Display is only active for operation with standard devices of the 8200 vector or 8200 motec series
	Code level	Two-digit subcode number	
<b>G</b>	<b>Parameter value</b>		
		Parameter value with unit	
<b>H</b>	<b>Cursor</b>		
		In the parameter level, the digit above the cursor can be directly changed	
<b>I</b>	<b>Function keys</b>		
		For description see the following table	

### Function keys



#### Note!

Shortcuts with **SHIFT**:

Press and hold **SHIFT**, then press the second key in addition.

Key	Function			
	Menu level	Code level	Parameter level	Operating level
<b>PRG</b>		Change to the parameter level	Change to the operating level	Change to the code level
<b>SHIFT</b> <b>PRG</b>	Go to the "Short setup" menu and load predefined configurations <sup>1)</sup>		Accept parameters when SHPRG → or SHPRG is displayed	
<b>↕</b>	Change between menu items	Change of code number	Change of digit via cursor	
<b>SHIFT</b> <b>↕</b> <b>SHIFT</b> <b>↕</b>	Quick change between menu items	Quick change of code number	Quick change of digit via cursor	
<b>→</b> <b>←</b>	Change between main menu, submenu and code level		Cursor to the right Cursor to the left	
<b>RUN</b>	Deactivate the function of the key <b>STOP</b> , the LED in the key goes off			
<b>STOP</b>	Inhibit the controller, the LED in the key is lit.			
	Reset fault (TRIP-Reset):			
	1. Remove the cause of malfunction			
	2. Press <b>STOP</b>			
	3. Press <b>RUN</b>			

<sup>1)</sup> Only active for operation with standard devices of the 8200 vector or 8200 motec series

3.1.4 Changing and saving parameters



**Note!**



Your settings have an effect on the current parameters in the main memory. You must save your settings in a parameter set so that they are not lost when the mains are connected.


If you only need one parameter set, save your settings as parameter set 1, since parameter set 1 is loaded automatically after mains connection.

Step		Key sequence	Action
1.	Select the menu	⬆ ⬇ ⬆ ⬇	Use the arrow keys to select the desired menu
2.	Change to the code level	⬆	Display of the first code in the menu
3.	Select code or subcode	⬇ ⬆	Display of the current parameter value
4.	Change to the parameter level	PRG	
5.	When SHPRG is displayed, inhibit the controller	STOP 1)	The drive coasts
6.	Change parameter	A ⬆ ⬇	Move cursor below the digit to be changed
		B ⬇ ⬆	Change of digit
		SHIFT ⬇	Quick change of digit
		SHIFT ⬆	
7.	Accept the changed parameter		
	Display of SHPRG or SHPRG →	SHIFT PRG	Confirm change to accept the parameter Display "OK"
	Display →	-	The parameter has been accepted immediately
8.	Enable the controller, if required	RUN 1)	The drive runs again
9.	Change to the code level	A PRG	Display of the operating level
		B PRG	Display of the code with changed parameter
10.	Change further parameters		Restart the "loop" with step 1. or 3.
11.	Save changed parameters	A ⬆ ⬇ ⬆ ⬇	Select the code C0003 "PAR SAVE" in the menu "Load/Store"
		B PRG	Change to the parameter level Display "0" and "READY"
		C ⬆	Save as parameter set 1: ⇒ Set "1" "Save PS1"
			Save as parameter set 2: ⇒ Set "2" "Save PS2"
			Save as parameter set 3: ⇒ Set "3" "Save PS3"
Save as parameter set 4: ⇒ Set "4" "Save PS4"			
D SHIFT PRG	When "OK" is displayed, the settings are permanently saved in the selected parameter set.		

## Parameter setting

Parameter setting with the XT EMZ9371BC keypad  
Changing and saving parameters

Step	Key sequence	Action
12. Change to the code level	A 	Display of the operating level
	B 	Display of C0003 "PAR SAVE"
13. Set parameters for another parameter set		Restart the "loop" with step 1. or 3.

- <sup>1)</sup> The function of the  key can be programmed:  
C0469 = 1: Controller inhibit  
C0469 = 2: Quick stop (Lenze setting)



### 3.1.5 Loading a parameter set

The keypad serves to load a saved parameter set into the main memory when the controller is inhibited. After the controller is enabled, it operates with the new parameters.



#### Danger!

- ▶ When a new parameter set is loaded, the controller is reinitialised and acts as if it had been connected to the mains:
  - System configurations and terminal assignments can be changed. Make sure that your wiring and drive configuration comply with the settings of the parameter set.
- ▶ Only use terminal X5/28 as source for the controller inhibit! Otherwise the drive may start in an uncontrolled way when switching over to another parameter set.



#### Note!

- ▶ After switching on the supply voltage, the controller always loads parameter set 1 into the main memory.
- ▶ It is also possible to load other parameter sets into the main memory via the digital inputs or bus commands.

Step		Key sequence	Action
1.	Inhibit controller		Terminal X5/28 = LOW
2.	Load the saved parameter set into the main memory		
		A ▲ ▼ ▶ ◀	Select the code C0002 "PAR LOAD" in the menu "Load/Store"
		B PRG	Change to the parameter level The active parameter set is displayed, e. g. display "0" and "Load Default" If you want to restore the delivery status, proceed with D
	Select the parameter set to be loaded	C ▲	Load parameter set 1: ⇒ Set "1" "Load PS1" Load parameter set 2: ⇒ Set "2" "Load PS2" Load parameter set 3: ⇒ Set "3" "Load PS3" Load parameter set 4: ⇒ Set "4" "Load PS4"
		D SHIFT PRG	"RDY" goes off. The parameter set is loaded completely into the main memory if "RDY" is displayed again.
3.	Change to the code level		
		A PRG	Display of the operating level
		B PRG	Display of C0002 "PAR LOAD"
4.	Enable controller		Terminal X5/28 = HIGH The drive is running with the settings of the loaded parameter set

## Parameter setting

Parameter setting with the XT EMZ9371BC keypad  
Transferring parameters to other standard devices

### 3.1.6 Transferring parameters to other standard devices

Parameter settings can be easily copied from one standard device to another by using the keypad.

For this purpose use the "Load/Store" menu



#### Danger!

During the parameter transfer from the keypad to the standard device the control terminals can adopt undefined states!

Therefore the plugs X5 and X6 must be disconnected from the standard device before the transfer takes place. This ensures that the controller is inhibited and all control terminals have the defined state "LOW".

### Copying parameter sets from the standard device into the keypad



#### Note!

After copying the parameter sets into the XT keypad (C0003 = 11), always the parameter set that was loaded last via C0002 is activated.

Like this the current parameters also remain active after copying:

- ▶ Save the current parameters in the parameter set before copying and load this parameter set in the controller via C0002.

Step	Key sequence	Action
1.	Connect the keypad to standard device 1	
2.	Inhibit controller	Terminal X5/28 = LOW The drive coasts.
3.	Select C0003 in the "Load/Store" menu	◀ ▶ ◀ ▶ ◀ ▶ ◀ ▶ Select code C0003 "PAR SAVE" in the "Load/Store" menu using the arrow keys.
4.	Change to the parameter level	PRG Display "0" and "READY"
5.	Copy all parameter set into the keypad	The settings saved in the keypad are overwritten. ▶ Set "11" "Save extern"
6.	Start copying	SHIFT PRG The "RDY" status display goes off. As parameter value "BUSY" is displayed. If "BUSY" goes off after approx. one minute, all parameter sets were copied into the keypad. The "RDY" status display is lit.
7.	Change to the code level	A PRG B PRG Display of the operating level Display C0003 and "PAR SAVE"
8.	Enable controller	Terminal X5/28 = HIGH
9.	Remove keypad from standard device 1	

## Copying parameter sets fom keypad into the standard device

Step	Key sequence	Action
1.		Connect the keypad to standard device 2
2.		Inhibit controller Terminal X5/28 = LOW The "IMP" status display is it. The drive coasts
3.		Pull the plugs X5 and X6 All control terminals have the defined "LOW" status.
4.	◀ ▶ ◂ ◃	Select C0002 in the "Load/Store" menu Select code C0002 "PAR LOAD" in the "Load/Store" menu using the arrow keys.
5.	PRG	Change to the parameter level The active parameter set is shown, e. g. display "0" and "Load Default"
6.		Select the correct copy function The settings saved in the standard device are overwritten.
		<ul style="list-style-type: none"> <li>Copy all parameter sets available into the EEPROM of the standard device and save them permanently.</li> <li>The parameter set that was active before copying is overwritten.</li> <li>The parameters are not yet active after copying. Select parameter set and load it in the main memory.  25</li> </ul>
	▲	Set "20" "ext -> EEPROM"
		<ul style="list-style-type: none"> <li>Copy individual parameter sets into the main memory of the standard device.</li> </ul>
	▲	Copy parameter set 1 into the main memory: Set ⇒ "11" "Load ext PS1"
		Copy parameter set 2 into the main memory: Set ⇒ "12" "Load ext PS2"
		Copy parameter set 3 into the main memory: Set ⇒ "13" "Load ext PS3"
		Copy parameter set 4 into the main memory: Set ⇒ "14" "Load ext PS4"
7.	SHIFT PRG	Start copying The "RDY" status display goes off. As parameter value "BUSY" is displayed. If "BUSY" goes off, the parameter sets selected were copied into the standard device. The "RDY" status display is lit.
8.	A	Change to the code level Display of the operating level
	B	Display C0002 and "PAR LOAD"
9.	◀ ▶ ◂ ◃	<ul style="list-style-type: none"> <li>If the function "Copy all parameter sets into the EEPROM" (C0002 = 20) is selected, they might have to be loaded in the main memory manually.</li> <li>If the function "Copy individual parameter sets into the main memory" (C0002 = 1x) is selected, they might have to be saved permanently in the EEPROM manually.</li> </ul>
10.		Plug in plugs X5 and X6
11.		Enable controller Terminal X5/28 = HIGH The drive is running with the new settings.

## Parameter setting

Parameter setting with the XT EMZ9371BC keypad  
Activating password protection

### 3.1.7 Activating password protection



#### Note!

- ▶ If the password protection is activated (C0094 = 1 ... 9999), you only have free access to the user menu.
- ▶ To access the other menus, you must enter the password. By this, the password protection is annulled until you enter a new password.
- ▶ Please observe that the password-protected parameters can be overwritten as well when transferring the parameter sets to other standard devices. The password is not transferred.
- ▶ Do not forget your password! If you have forgotten your password, it can only be reset via a PC or a bus system!

#### Activate password protection

Step	Key sequence	Action
1. Select the "USER menu"	⬆ ⬇ ⬆ ⬇	Change to the user menu using the arrow keys
2. Change to the code level	▶	Display of code C0051 "MCTRL-NACT"
3. Select C0094	▲	Display of code C0094 "Password"
4. Change to the parameter level	PRG	Display "0" = no password protection
5. Set password	A ▲	Select password (1 ... 9999)
	B SHIFT PRG	Confirm password
6. Change to the code level	A PRG	Display of the operating level
	B PRG	Display of C0094 and "Password"
7. Change to the "USER menu"	⬆ ⬇ ⬆	

The password protection is active now.

You can only quit the user menu if you re-enter the password and confirm it with SHIFT PRG.

#### Remove password protection

Step	Key sequence	Action
1. Change to the code level in the user menu	▶	
2. Select C0094	▲	Display of code C0094 "Password"
3. Change to the parameter level	PRG	Display "9999" = password protection is active
4. Enter password	A ▼	Set valid password
	B SHIFT PRG	Confirm The password protection is deactivated by entering the password once again.
5. Change to the code level	A PRG	Display of the operating level
	B PRG	Display of C0094 and "Password"

The password protection is deactivated now. All menus can be freely accessed again.

### 3.1.8 Diagnostics

In the "Diagnostic" menu the two submenus "Actual info" and "History" contain all codes for

- ▶ monitoring the drive
- ▶ fault/error diagnosis

In the operating level, more status messages are displayed. If several status messages are active, the message with the highest priority is displayed.

Priority	Display	Meaning
1	GLOBAL DRIVE INIT	Initialisation or communication error between keypad and controller
2	XXX - TRIP	Active TRIP (contents of C0168/1)
3	XXX - MESSAGE	Active message (contents of C0168/1)
4	Special device states:	Switch-on inhibit
5	Source for controller inhibit (the value of C0004 is displayed simultaneously):	
	STP1	9300 servo: Terminal X5/28 ECSxS/P/M/A: Terminal X6/SI1
	STP3	Operating module or LECOM A/B/LI
	STP4	INTERBUS or PROFIBUS-DP
	STP5	9300 servo, ECSxA/E: System bus (CAN) ECSxS/P/M: MotionBus (CAN)
	STP6	C0040
6	Source for quick stop (QSP):	
	QSP-term-Ext	The MCTRL-QSP input of the MCTRL function block is on HIGH signal.
	QSP-C0135	Operating module or LECOM A/B/LI
	QSP-AIF	INTERBUS or PROFIBUS-DP
	QSP-CAN	9300 servo, ECSxA: System bus (CAN) ECSxS/P/M: MotionBus (CAN)
7	XXX - WARNING	Active warning (contents of C0168/1)
8	xxxx	Value below C0004

## 3.1.9 Menu structure

For simple, user-friendly operation, the codes are clearly arranged in function-related menus:

Main menu	Submenus	Description
Display	Display	
User-Menu		<b>Codes defined in C0517</b>
Code list		<b>All available codes</b>
	ALL	All available codes listed in ascending order (C0001 ... C7999)
	PS 1	Codes in parameter set 1 (C0001 ... C1999)
	PS 2	Codes in parameter set 2 (C2001 ... C3999)
	PS 3	Codes in parameter set 3 (C4001 ... C5999)
	PS 4	Codes in parameter set 4 (C6001 ... C7999)
Load/Store		<b>Parameter set management</b> Parameter set transfer, restore delivery status
Diagnostic		<b>Diagnostic</b>
	Actual info	Display codes to monitor the drive
	History	Fault analysis with history buffer
Short setup		<b>Quick configuration of predefined applications</b> <b>Configuration of the user menu</b> The predefined applications depend on the type of the standard device (frequency inverter, servo inverter, position controller, ...)
Main FB		<b>Configuration of the main function blocks</b>
	NSET	Setpoint processing
	NSET-JOG	Fixed setpoints
	NSET-RAMP1	Ramp function generator
	MCTRL	Motor control
	DFSET	Digital frequency processing
	DCTRL	Internal control
Terminal I/O		<b>Connection of inputs and outputs with internal signals</b>
	AIN1 X6.1/2	Analog input 1
	AIN2 X6.3/4	Analog input 2
	AOUT1 X6.62	Analog output 1
	AOUT2 X6.63	Analog output 2
	DIGIN	Digital inputs
	DIGOUT	Digital outputs
	DFIN	Digital frequency input
	DFOUT	Digital frequency output
	State bus	State bus (not with 9300 frequency inverter)
Controller		<b>Configuration of internal control parameters</b>
	Speed	Speed controller
	Current	Current controller or torque controller
	Phase	Phase controller (not with 9300 frequency inverter)
Motor/Feedb.		<b>Input of motor data, configuration of speed feedback</b>
	Motor adj	Motor data
	Feedback	Configuration of feedback systems
Monitoring		<b>Configuration of monitoring functions</b>

Main menu	Submenus	Description
<b>Display</b>	<b>Display</b>	
<b>LECOM/AIF</b>		<b>Configuration of operation with communication modules</b>
	LECOM A/B	Serial interface
	AIF interface	Process data
	Status word	Display of status words
<b>System bus</b>		<b>Configuration of system bus (CAN)</b>
	Management	CAN communication parameters
	CAN-IN1	CAN object 1
	CAN-OUT1	
	CAN-IN2	CAN object 2
	CAN-OUT2	
	CAN-IN3	CAN object 3
	CAN-OUT3	
	Status word	Display of status words
	FDO	Free digital outputs
	Diagnostic	CAN diagnostic
<b>FB config</b>		<b>Configuration of function blocks</b>
<b>Func blocks</b>		<b>Parameterisation of function blocks</b> The submenus contain all available function blocks
<b>FCODE</b>		<b>Configuration of free codes</b>
<b>Identify</b>		<b>Identification</b>
	Drive	Software version of standard device
	Op Keypad	Software version of keypad

## 4 Troubleshooting and fault elimination


### Display of operating data, diagnostics

## 4 Troubleshooting and fault elimination

### 4.1 Display of operating data, diagnostics

The dialog box displays important operating parameters and supports you in diagnosing the drive controller.

- ▶ Open the **Diagnostics** dialog box in the parameter menu.



9300std230

Fig. 4-1 "Diagnostics" dialog box

- ▶ You can recognise immediately that a fault has occurred from the display elements or status information.
- ▶ An error can be analysed with
  - the history buffer in Global Drive Control (GDC) (📖 34) or
  - the XT keypad
  - and with the "General error messages" table in the "System error messages" chapter.
- ▶ The "General error messages" table provides tips on how to eliminate an error.



## 4.2 Troubleshooting

### Detecting breakdowns

A breakdown can be detected quickly via the LEDs at the controller or via the status information at the keypad.

### Analysing errors

Analyse the error using the history buffer. The list of fault messages gives you advice how to remove the fault. (📖 36)

### 4.2.1 Status display via controller LEDs

During operation the operating status of the controller is shown by 2 LEDs.

LED		Operating status	
Red ①	Green ②		
Off	On	Controller enabled	
On	On	Mains switched on and automatic start inhibited	
Off	Blinking slowly	Controller inhibited	
Blinking quickly	Off	Undervoltage or overvoltage	
Blinking slowly	Off	Fault active	

## 4 Troubleshooting and fault elimination


### Troubleshooting

#### Fault analysis with the history buffer

#### 4.2.2 Fault analysis with the history buffer

The history buffer can be used to trace faults. The fault messages are stored in the 8 memory locations in the order of their occurrence.

- Open the **Diagnostics** dialog box in the parameter menu.



9300std230

Fig. 4-2 "Diagnostics" dialog box

Field	History buffer location	Entry	Note
① ② ③	1	Active fault	If the fault is no longer pending or has been acknowledged: <ul style="list-style-type: none"> <li>• The content of memory units 1 ... 7 is shifted "upwards" by one memory unit.</li> <li>• The content of memory unit 8 is removed from the history buffer and can no longer be retrieved.</li> <li>• Memory unit 1 is deleted (= no active fault).</li> </ul>
	2	Last fault	
	3	Next to last fault	
	4	Third to last fault	
④ ⑤ ⑥	5	Fourth to last fault	
	6	Fifth to last fault	
	7	Sixth to last fault	
	8	Seventh to last fault	

#### Explanations

①, ④	<b>Fault indication and fault response (C0168)</b> <ul style="list-style-type: none"> <li>• The entry is effected as LECOM error number.</li> <li>• If several faults with a different response occur at the same time:                             <ul style="list-style-type: none"> <li>– Only the fault the response of which has the highest priority is entered (1. TRIP, 2. message, 3. warning).</li> </ul> </li> <li>• If faults with the same response occur (e. g. 2 messages) at the same time:                             <ul style="list-style-type: none"> <li>– Only the fault that was triggered first is entered.</li> <li>– The OH7 and OH3 warnings are exceptions. If an OH7 warning is pending and the OH3 motor temperature threshold is reached, the OH7 warning is overwritten by the OH3 warning. If the motor temperature decreases again, the OH7 warning reappears.</li> </ul> </li> </ul>
②, ⑤	<b>Time of the fault (C0169)</b> <ul style="list-style-type: none"> <li>• Reference time is the content of the power-on time meter ⑨.</li> <li>• If a fault is immediately followed by another fault for several times, only the time of the last occurrence is stored.</li> </ul>
③, ⑥	<b>Frequency of occurrence of the fault (C0170)</b> <ul style="list-style-type: none"> <li>• The time of the last occurrence is stored.</li> </ul>
⑦	Click on <b>Fault memory reset</b> to clear the history buffer. The history buffer can only be cleared if no fault is active.
⑧	Click on <b>TRIP reset</b> to reset the fault.

## 4.2.3 Fault analysis via LECOM status words (C0150/C0155)

The LECOM status words (C0150/C0155) are coded as follows:

Code		Possible settings		IMPORTANT
No.	Designation	Lenze/ {Appl.}	Selection	
C0150	Status word	0		Device status word for networking via automation interface (AIF) Read only
			0	{1}
			Bit 0 Not assigned Bit 1 Pulse inhibit (IMP) Bit2 Not assigned Bit3 Not assigned Bit4 Not assigned Bit5 Not assigned Bit 6 n = 0 Bit 7 Controller inhibit (CINH) Bit 8 Device status bit 1 Bit 9 Device status bit 2 Bit10 Device status bit 3 Bit11 Device status bit 4 Bit12 Warning Bit13 Message Bit14 Not assigned Bit15 Not assigned	
C0155	Status word 2	0		Status word 2 (advanced status word) Display only
			0	{1}
			Bit 0 Active fault Bit 1 $M_{max}$ reached Bit 2 $I_{max}$ reached Bit 3 Pulse inhibit(IMP) Bit 4 Ready for operation (RDY) Bit 5 Controller inhibit (CINH) Bit 6 TRIP active Bit 7 Initialisation Bit 8 Motor direction of rotation (Cw/CCw) Bit 9 Not assigned Bit 10 Not assigned Bit 11 Not assigned Bit 12 Not assigned Bit 13 Not assigned Bit 14 Not assigned Bit 15 Not assigned	

## 4 Troubleshooting and fault elimination

System error messages  
General error messages

### 4.3 System error messages

#### 4.3.1 General error messages



#### Note!

In the case of a query via system bus (CAN), the fault messages are represented as numbers (see first column of the table).

Fault message		Description	Cause	Remedy
No.	Display			
---	---	No fault	-	-
0011	OC1	Short circuit of motor cable	Short circuit	<ul style="list-style-type: none"> <li>● Search for cause of short circuit.</li> <li>● Check motor cable.</li> </ul>
			Excessive capacitive charging current in the motor cable.	Use motor cable which is shorter or of lower capacitance.
0012	OC2	Motor cable earth fault	One of the motor phases has earth contact.	<ul style="list-style-type: none"> <li>● Search for cause of short circuit.</li> <li>● Check motor cable.</li> </ul>
0015	OC5	$I \times t$ overload	<ul style="list-style-type: none"> <li>● Frequent and too long acceleration with overcurrent</li> <li>● Continuous overload with <math>I_{\text{motor}} &gt; 1.05 \times I_{\text{rx}}</math>.</li> </ul>	Check drive dimensioning.
0016	OC6	$I^2 \times t$ overload	<ul style="list-style-type: none"> <li>● Frequent and too long acceleration processes with motor overcurrent.</li> <li>● Permanent motor overload with <math>I_{\text{motor}} &gt; I_{\text{r motor}}</math></li> </ul>	Check drive dimensioning.
x018	OC8	$I^2 \times t$ overload advance warning	<ul style="list-style-type: none"> <li>● Frequent and too long acceleration processes with motor overcurrent.</li> <li>● Permanent motor overload with <math>I_{\text{motor}} &gt; I_{\text{r motor}}</math></li> </ul>	Check drive dimensioning.
1020	OU	Overvoltage in DC bus	Braking energy is too high. (DC-bus voltage is higher than set in C0173.)	<ul style="list-style-type: none"> <li>● Use braking unit or regenerative module.</li> <li>● Check dimensioning of the brake resistance.</li> </ul>
1030	LU	Undervoltage in the DC bus	DC bus voltage is lower than specified in C0173.	<ul style="list-style-type: none"> <li>● Check mains voltage</li> <li>● Check supply cable</li> </ul>
x032	LP1	Motor phase failure	A current-carrying motor phase has failed.	<ul style="list-style-type: none"> <li>● Check motor.</li> <li>● Check motor cable.</li> <li>● Switch off monitoring (C0597 = 3).</li> </ul>
			The current limit value is set too low.	● Set higher current limit value via C0599.
0050	OH	Heatsink temperature > +90 °C	Ambient temperature $T_u > +40 \text{ °C}$ or $> +50 \text{ °C}$	<ul style="list-style-type: none"> <li>● Allow module to cool and ensure better ventilation.</li> <li>● Check ambient temperature in the control cabinet.</li> </ul>
			Heatsink is very dirty.	Clean heatsink.
			Wrong mounting position	Change mounting position.

Fault message		Description	Cause	Remedy
No.	Display			
x053	OH3	Motor temperature > +150 °C threshold (temperature detection via resolver or incremental value encoder)	Motor is thermally overloaded due to: <ul style="list-style-type: none"> <li>● Impermissible continuous current</li> <li>● Frequent or too long acceleration processes</li> </ul>	<ul style="list-style-type: none"> <li>● Check drive dimensioning.</li> <li>● Switch off monitoring (C0583 = 3).</li> </ul>
			No PTC/temperature contact connected.	Correct wiring.
x054	OH4	Heatsink temperature > C0122	Ambient temperature $T_u > +40\text{ °C}$ or $> +50\text{ °C}$	<ul style="list-style-type: none"> <li>● Allow module to cool and ensure better ventilation.</li> <li>● Check ambient temperature in the control cabinet.</li> <li>● Switch off monitoring (C0582 = 3).</li> </ul>
			Heatsink is very dirty.	Clean heatsink
			Wrong mounting position	Change mounting position.
			The value specified under C0122 is set too low.	Enter a higher value under C0122.
x057	OH7	Motor temperature > C0121 (temperature detection via resolver or incremental value encoder)	Motor is thermally overloaded due to: <ul style="list-style-type: none"> <li>● Impermissible continuous current</li> <li>● Frequent or too long acceleration processes</li> </ul>	<ul style="list-style-type: none"> <li>● Check drive dimensioning.</li> <li>● Switch off monitoring (C0584 = 3).</li> </ul>
			No PTC/temperature contact connected.	Correct wiring.
			The value specified under C0121 is set too low.	Enter a higher value in C0121.
x058	OH8	Motor temperature via inputs T1 and T2 is too high.	Motor is thermally overloaded due to: <ul style="list-style-type: none"> <li>● Impermissible continuous current</li> <li>● Frequent or too long acceleration processes</li> </ul>	<ul style="list-style-type: none"> <li>● Check drive dimensioning.</li> <li>● Switch off monitoring (C0585 = 3).</li> </ul>
			Terminals T1 and T2 are not connected	Connect PTC/temperature contact.
x061	CE0	Automation interface (AIF) communication error	Faulty transfer of control commands via AIF.	<ul style="list-style-type: none"> <li>● Plug in the communication module/keypad XT firmly, screw down, if necessary.</li> <li>● Switch off monitoring (C0126 = 3).</li> </ul>
x062	CE1	Communication error on the process data input object CAN1_IN	CAN1_IN object receives faulty data or communication is interrupted.	<ul style="list-style-type: none"> <li>● Check wiring at X4.</li> <li>● Check sender.</li> <li>● Increase monitoring time under C0357/1, if necessary.</li> <li>● Switch off monitoring (C0591 = 3).</li> </ul>
x063	CE2	Communication error on the process data input object CAN2_IN	CAN2_IN object receives faulty data or communication is interrupted.	<ul style="list-style-type: none"> <li>● Check wiring at X4.</li> <li>● Check sender.</li> <li>● Increase monitoring time under C0357/2, if necessary.</li> <li>● Switch off monitoring (C0592 = 3).</li> </ul>
x064	CE3	Communication error on the process data input object CAN3_IN	CAN3_IN object receives faulty data or communication is interrupted.	<ul style="list-style-type: none"> <li>● Check wiring at X4.</li> <li>● Check sender.</li> <li>● Increase monitoring time under C0357/3, if necessary.</li> <li>● Switch off monitoring (C0593 = 3).</li> </ul>

## 4 Troubleshooting and fault elimination

### System error messages General error messages

Fault message		Description	Cause	Remedy
No.	Display			
x065	CE4	BUS-OFF state of system bus (CAN)	The controller has received too many faulty telegrams via the system bus (CAN) and has disconnected from the bus.	<ul style="list-style-type: none"> <li>● Check wiring at X4: Is the bus correctly terminated?</li> <li>● Check shield connection of the cables.</li> <li>● Check PE connection.</li> <li>● Check bus load, reduce the baud rate if necessary. (Observe the cable length!)</li> <li>● Switch off the monitoring (C0595 = 3).</li> </ul>
x066	CE5	Time-out of system bus (CAN) (communication error of gateway function)	For remote parameterisation (C0370, C0371) via system bus (CAN): <ul style="list-style-type: none"> <li>● Slave does not respond.</li> <li>● Communication monitoring time has been exceeded.</li> </ul>	<ul style="list-style-type: none"> <li>● Check wiring of system bus (CAN).</li> <li>● Check CAN bus configuration.</li> </ul>
0070	U15	Undervoltage of internal 15 V voltage supply		Check voltage supply.
0071	CCr	System failure	Strong interference injection on the control cables Ground or earth loops in the wiring	Screen control cables <ul style="list-style-type: none"> <li>● Check wiring</li> <li>● Check PE connection</li> </ul> <b>After troubleshooting: Deenergise the device completely (disconnect 24 V supply, discharge DC bus)!</b>
0072	PR1	Checksum error in parameter set 1 <b>CAUTION: The Lenze setting is loaded automatically!</b>	<ul style="list-style-type: none"> <li>● Fault when loading a parameter set.</li> <li>● Interruption while transmitting the parameter set via keypad.</li> </ul> The stored parameters are incompatible with the loaded software version.	<ul style="list-style-type: none"> <li>● Set the required parameters and store them under C0003 = 1.</li> <li>● As to PLC devices, check the use of pointers.</li> </ul> Store the parameter set under C0003 = 1 first to allow for a faults reset.
0073	PR2	Checksum error in parameter set 2 <b>PLEASE NOTE: The Lenze setting is loaded automatically!</b>	<ul style="list-style-type: none"> <li>● Fault while loading a parameter set.</li> <li>● Interruption during the transfer of the parameter set via keypad.</li> </ul> The parameters saved do not comply with the software version loaded.	<ul style="list-style-type: none"> <li>● Set the required parameters and save them with C0003 = 2.</li> </ul> In order to be able to acknowledge the error, first save the parameter set with C0003 = 2.
0074	PEr	Program error	Error in the program flow	Send the parameter set (on floppy disk/CD-ROM) with a detailed description of the problem to Lenze. <b>After troubleshooting: Deenergise the device completely (disconnect 24 V supply, discharge DC bus)!</b>
0075	PR0	Error in parameter set.	The operating system software has been updated.	Storage of the Lenze setting C0003 = 1. <b>After troubleshooting: Deenergise the device completely (disconnect 24 V supply, discharge DC bus)!</b>
0077	PR3	Checksum error in parameter set 3 <b>PLEASE NOTE: The Lenze setting is loaded automatically!</b>	<ul style="list-style-type: none"> <li>● Fault while loading a parameter set.</li> <li>● Interruption during the transfer of the parameter set via keypad.</li> </ul> The parameters saved do not comply with the software version loaded.	<ul style="list-style-type: none"> <li>● Set the required parameters and save them with C0003 = 3.</li> </ul> In order to be able to acknowledge the error, first save the parameter set with C0003 = 3.

Fault message		Description	Cause	Remedy
No.	Display			
0078	PR4	Checksum error in parameter set 4 <b>PLEASE NOTE: The Lenze setting is loaded automatically!</b>	<ul style="list-style-type: none"> <li>● Fault while loading a parameter set.</li> <li>● Interruption during the transfer of the parameter set via keypad.</li> </ul>	<ul style="list-style-type: none"> <li>● Set the required parameters and save them with C0003 = 4.</li> </ul>
			The parameters saved do not comply with the software version loaded.	In order to be able to acknowledge the error, first save the parameter set with C0003 = 4.
0079	PI	Fault during parameter initialisation	<ul style="list-style-type: none"> <li>● An error has been detected during the parameter set transfer between two devices.</li> <li>● The parameter set does not match the controller, e.g. if data has been transferred from a higher-power controller to a lower-power controller.</li> </ul>	<ul style="list-style-type: none"> <li>● Correct parameter set.</li> <li>● Send parameter set (on floppy disk/CD-ROM) and a detailed description of the problem to Lenze.</li> </ul>
0080	PR6	Too many user codes		Reduce the number of user codes.
x082	Sd2	Resolver error at X7	Resolver cable interrupted.	<ul style="list-style-type: none"> <li>● Check cable for open circuit.</li> <li>● Check resolver.</li> <li>● Switch off the monitoring (C0586 = 3).</li> </ul>
x083	Sd3	Encoder error at X9	Cable interrupted.	Check cable for open circuit.
			Pin X9/8 not connected.	Apply 5 V to pin X9/8 or switch off monitoring (C0587 = 3).
x085	Sd5	Encoder error at X6/1 and X6/2 (C0034 = 1)	Current signal at X6/1 X6/2 < 2mA.	<ul style="list-style-type: none"> <li>● Check cable for open circuit.</li> <li>● Check current signal encoder.</li> <li>● Switch off monitoring (C0598 = 3).</li> </ul>
x086	Sd6	Motor temperature sensor error (X7 or X8)	Encoder for detecting the motor temperature at X7 or X8 indicates undefined values.	<ul style="list-style-type: none"> <li>● Check cable for firm connection.</li> <li>● Switch off the monitoring (C0594 = 3).</li> </ul>

Fault message		Description	Cause	Remedy
No.	Display			
x087	Sd7	Selection of the feedback in C0025 as absolute value encoder or alteration of the encoder constant in C0420 for setting $C0025 \geq 309$	The absolute value encoder must be initialised.	Save parameter set, then completely deenergise the device, and afterwards switch it on again.
		Initialisation error of absolute value encoder at X8	<ul style="list-style-type: none"> <li>Defect of the encoder electronics</li> <li>Absolute value encoder at X8 does not send data.</li> </ul> <p><b>Tip:</b> The encoder must not rotate during mains switching.</p>	<ul style="list-style-type: none"> <li>Make sure that the cable at X8 is tightened properly, and check it with regard to open circuit.</li> <li>Check absolute value encoder with regard to correct function.</li> <li>Set voltage supply via C0421 to 8.0 V.</li> <li>No Stegmann encoder connected.</li> <li>Replace defective encoder.</li> </ul>
		Communication error of absolute value encoder at X8 during rotor position adjustment	A rotor position adjustment via C0095 = 1 could not be completed successfully.	Repeat rotor position adjustment.  <b>Note:</b> After an Sd7 fault it is absolutely required to carry out another rotor position adjustment. Otherwise the drive may carry out uncontrolled movements after controller enable. The drive must not be commissioned without a successfully executed rotor position adjustment!
				<b>After fault elimination: Completely deenergise device (switch off 24 V supply, discharge DC bus)!</b>
x088	Sd8	SinCos encoder at X8 sends inconsistent data.	The tracks in the SinCos encoder are damaged.	Replace SinCos encoder.
			Interference level on the encoder cable is too high.	<ul style="list-style-type: none"> <li>Check correct shield connection of encoder cable.</li> <li>Where required, decelerate the actuation of the fault message via the filter time constant. Setting: <ul style="list-style-type: none"> <li>– for ECSxS/P/M/A in C0559.</li> <li>– for 9300 servo cam in C0575.</li> </ul> </li> </ul>
		SinCos encoder at X8 does not send any data.	Open circuit.	Check cable for wire breakage.
			Incorrect encoder connected.	Connect SinCos encoder of the Stegmann company.
			SinCos encoder is defective.	Replace SinCos encoder.
	Supply voltage set incorrectly.	Set voltage supply in C0421.		
		<b>After fault correction: completely deenergise the device (switch off 24 V supply, discharge DC bus)!</b>		
x089	PL	Error during rotor position adjustment (the error is saved with mains failure protection)	<ul style="list-style-type: none"> <li>The rotor position adjustment was cancelled.</li> <li>During rotor position adjustment with an absolute value encoder the error Sd7 or SD8 occurred.</li> </ul>	Repeat rotor position adjustment.  <b>Note:</b> After an Sd7 fault it is absolutely required to carry out another rotor position adjustment. Otherwise the drive may carry out uncontrolled movements after controller enable. The drive must not be commissioned without a successfully executed rotor position adjustment!



Fault message		Description	Cause	Remedy
No.	Display			
x091	EEr	External monitoring has been triggered via DCTRL.	A digital signal assigned to the TRIP-SET function has been activated.	<ul style="list-style-type: none"> <li>Check external encoder.</li> <li>Switch off the monitoring (C0581 = 3).</li> </ul>
0105	H05	Internal fault (memory)		Contact Lenze.
0107	H07	Internal fault (power stage)	During initialisation of the controller, an incorrect power stage was detected.	Contact Lenze.
x110	H10	Heatsink temperature sensor error	Sensor for detecting the heatsink temperature indicates undefined values.	<ul style="list-style-type: none"> <li>Contact Lenze.</li> <li>Switch off the monitoring (C0588 = 3).</li> </ul>
x111	H11	Temperature sensor error: Temperature inside the controller	Sensor for detecting the internal temperature indicates undefined values.	<ul style="list-style-type: none"> <li>Contact Lenze.</li> <li>Switch off the monitoring (C0588 = 3).</li> </ul>
x151	P01	Error "negative limit switch".	Negative limit switch was reached.	<ul style="list-style-type: none"> <li>Control drive in positive direction</li> <li>Check wiring at X5/E2.</li> </ul>
x152	P02	Error "positive limit switch".	Positive limit switch was reached.	<ul style="list-style-type: none"> <li>Control drive in negative direction</li> <li>Check wiring at X5/E1.</li> </ul>
x153	P03	Following error	The angle difference between set and actual position is larger than the following error limit set under C0255. Drive cannot follow the digital frequency ( $I_{max}$ limit).	<ul style="list-style-type: none"> <li>Increase following error limit under C0255.</li> <li>Switch off the monitoring (C0589 = 3).</li> </ul> Check drive dimensioning.
x154	P04	Error "negative position limit".	Negative position limit (C1224) was not reached.	Find out why the value was not reached (e.g. "incorrect" position targets, set function position value) and adjust the position limit in C1224 if necessary.
x155	P05	Error "positive position limit".	Positive position limit (C1223) was exceeded.	Find out why the value was exceeded (e.g. "incorrect" position targets, set function position value) and adjust the position limit in C1223 if necessary.
x156	P06	No reference.	The reference point is not known. In the case of absolute positioning, no homing was performed before the first positioning.	Perform one of the following functions and restart: <ul style="list-style-type: none"> <li>Manual homing.</li> <li>Start homing in the program.</li> <li>Set reference.</li> </ul>
x157	P07	Parameter set mode is absolute instead of relative.	An absolute parameter set (C1311) was performed during relative positioning (position mode C1210).	Perform one of the following functions and restart: <ul style="list-style-type: none"> <li>Change the parameter set from absolute to relative.</li> <li>Change position mode.</li> </ul>
x158	P08	Error "actual reference dimension offset".	Actual reference dimension offset (C1226) outside the position limits. Error of the program function "set position value".	If necessary, adapt the position limit values or check whether the program function "set position value" is to be applied.
x159	P09	Error in positioning program.	Impermissible programming	Check position program: <ul style="list-style-type: none"> <li>A parameter set with final speed must be followed by a parameter set with positioning; it is not permissible to wait for input.</li> </ul>

## 4

# Troubleshooting and fault elimination

## System error messages

### General error messages

Fault message		Description	Cause	Remedy
No.	Display			
x162	P12	Error in the range of the encoder.	The range of the absolute encoder was exceeded.	<ul style="list-style-type: none"> <li>Return drive by manual positioning.</li> <li>Check position limits and adjustment of the encoder.</li> <li>Design and mount the absolute encoder in a way that does not exceed the traversing range.</li> </ul>
x163	P13	Angle overrun.	<ul style="list-style-type: none"> <li>Phase controller limit reached</li> <li>Drive cannot follow the digital frequency (<math>I_{max}</math> limit).</li> </ul>	<ul style="list-style-type: none"> <li>Enable drive</li> <li>Check drive dimensioning.</li> </ul>
x164	P14	1. Following error.	The drive cannot follow the setpoint. The following error is greater than the limit value in C1218/1.	<ul style="list-style-type: none"> <li>Increase current limit under C0022 (observe max. motor current).</li> <li>Reduce acceleration.</li> <li>Check drive dimensioning.</li> <li>Increase limit value under C1218/1</li> </ul>
x165	P15	2. Following error.	The drive cannot follow the setpoint. The following error is greater than the limit value in C1218/2.	<ul style="list-style-type: none"> <li>Increase current limit C0022 (observe max. motor current).</li> <li>Reduce acceleration.</li> <li>Check drive dimensioning.</li> <li>Increase limit value under C1218/2</li> </ul>
x166	P16	Faulty transfer of system bus (CAN) sync telegram.	The sync telegram from the master (PLC) is out of sync cycle.	<ul style="list-style-type: none"> <li>Set the "sync cycle" to the transmission cycle of the master (PLC) under C1121.</li> <li>Note: <ul style="list-style-type: none"> <li>– C0362 displays the time interval between 2 sync telegrams.</li> <li>– C0362 = 0: communication interrupted.</li> </ul> </li> </ul>
			The sync telegram of the master (PLC) is not received.	<ul style="list-style-type: none"> <li>Check communication channel.</li> <li>Check baud rate, controller address.</li> <li>Note: <ul style="list-style-type: none"> <li>– C0362 displays the time interval between 2 sync telegrams.</li> <li>– C0362 = 0: communication interrupted.</li> </ul> </li> </ul>
			The controller is enabled too fast.	Delay the controller enable. The time delay required depends on the time interval between the sync telegrams.
x167	P17	Error "touch probe control".	Various function blocks use the touch probe input at the same time (e.g. FB DFSET and POS). A conflict arises.	<ul style="list-style-type: none"> <li>Configure another touch probe input for FB POS (not possible for FB DFSET).</li> <li>Switch off monitoring (C1289/1).</li> </ul>

Fault message		Description	Cause	Remedy
No.	Display			
x168	P18	Internal limitation.	Arithmetic operation generated data cannot be varied arbitrarily. Wrongly specified values were automatically limited internally.	
			C1298 = 1: The negative position limit in C1223 is outside the possible display range of $1 \leq (C1223 \times C1205) \leq 1.07E9 \text{ inc}$	Check the values in C1202/4, C1207/1, C1207/2. Read out the limited value in C1220/10 and enter it in C1223 if necessary.
			C1298 = 2: The positive position limit in C1224 is outside the possible display range of $1 \leq (C1224 \times C1205) \leq 1.07E9 \text{ inc}$	Check the values in C1202/4, C1207/1, C1207/2. Read out the limited value in C1220/11 and enter it in C1224 if necessary.
			C1298 = 3: The maximum speed $v_{\max}$ in C1240 is outside the possible display range of $1 \leq (C1240 \times C1205 \times 16.384) \leq 2.14E9 \text{ inc}$ or $v_{\max} \text{ not } C1240 / C1204 \times 60 \leq 1.5 \times n_{\max}$	Check the values in C0011, C1202/4, C1207/1, C1207/2. Read out the limited value in C1220/12 and enter it in C1240 or adjust the value in C1240 to C0011 if necessary.
			C1298 = 4: The maximum acceleration $a_{\max}$ in C1250 is outside the possible display range of $1 \leq (C1250 \times C1205 \times 16.384 / 1000) \leq 2.8634E7 \text{ inc}$	Check the values in C1202/4, C1207/1, C1207/2. Read out the limited value in C1220/13 and enter it in C1250 if necessary.
			C1298 = 5: An internal value range has been exceeded for a speed standardisation. Valid range: $1 \leq (C0011 \times C1207/1 / C1207/2) \leq 65536 / 60000 \leq 32767$	Check the values in C0011, C1207/1, C1207/2 and correct them.
x169	P19	The input values at X9 are limited.	The function block DFIN limits the input values. This causes the loss of increments.	<ul style="list-style-type: none"> <li>Reduce the frequency on the digital frequency connection.</li> <li>Check the settings for the slave (C0425) and for the master (C0030). These settings must be identical.</li> </ul>
x171	P21	Following error.	The phase difference between set and actual position is larger than the following error limit set under C1328.	<ul style="list-style-type: none"> <li>Extend the following error limit under C1328.</li> <li>Switch off monitoring (C1329=3).</li> </ul>
			Drive cannot follow the digital frequency ( $I_{\max}$ limit).	Check drive dimensioning.
x190	nErr	Speed control error (Speed out of tolerance margin (C0576))	<ul style="list-style-type: none"> <li>Active load (e.g. for hoists) is too high.</li> <li>Mechanical blockades on the load side</li> </ul>	Check drive dimensioning.
x200	NMAX	Maximum system speed (C0596) has been exceeded.	<ul style="list-style-type: none"> <li>Active load (e.g. for hoists) is too high.</li> <li>Drive is not speed-controlled, torque is excessively limited.</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Increase torque limit, if necessary.</li> <li>Switch off monitoring (C0607 = 3).</li> </ul>
0201	overrun Task1	Time-out in task 1 (ID 2)	Task processing takes longer than the monitoring time set.	<ul style="list-style-type: none"> <li>Adjust the length of the task runtime.</li> <li>Adjust monitoring time.</li> <li>Determine the cause of time-out by checking the task runtime at the task monitor.</li> <li>Swap out time-critical program parts in a slower task.</li> </ul>
...	...	...		
0208	overrun Task8	Time-out in task 8 (ID 9)		

## 4 Troubleshooting and fault elimination

### System error messages



#### General error messages

Fault message		Description	Cause	Remedy
No.	Display			
0209	float Sys-T	Float error in system task (ID 0)	Error in real calculation (e. g. division by 0)	Check calculations (program code).
0210	float Cycl.-T	Float error in cyclic task (PLC_PRG ID 1)		
0211	float Task1	Float error in task 1 (ID 2)		
...	...	...		
0218	float Task8	Float error in task 8 (ID 9)		
0219	overrun Cyc.-T	Time-out in cyclic task (PLC_PRG ID 1)	Task processing takes longer than the monitoring time set.	<ul style="list-style-type: none"> <li>Adjust the length of the task runtime.</li> <li>Adjust monitoring time.</li> <li>Determine the cause of time-out by checking the task runtime at the task monitor.</li> <li>Swap out time-critical program parts in a slower task.</li> </ul>
0220	noT-Fkt Credit	Not enough technology units available.	A program with technology functions has been tried to be loaded to a controller not providing the corresponding units.	<ul style="list-style-type: none"> <li>Use technology variant of the controller.</li> <li>Contact Lenze, if necessary.</li> </ul>
x220	CDA	Data error	Attempt to transmit faulty profile data	Repeat profile data transfer.
x221	CDA-LOAD	Faulty checksum	The checksum of the transferred profile data is not correct.	Repeat profile data transfer and check for correctness.
0230	No Program	Missing PLC program	No PLC program loaded.	Load PLC program.
0231	Unallowed Lib	PLC program calls invalid library function.	In the PLC program a library function has been called which is not supported by the controller (e.g. because the corresponding hardware is missing).	<ul style="list-style-type: none"> <li>Remove library function or ensure that the corresponding hardware is available.</li> <li>Contact Lenze, if necessary.</li> </ul>
0232	NoCam Data	Motion profiles (cam data) are not available.	When calling functions of the function library <b>LenzeCamControl.lib</b> it was detected that there are no motion profiles (CAM data) loaded in the memory of the controller.	<ul style="list-style-type: none"> <li>Ensure that the valid cam data has been attached to the project via the DDS CAM support.</li> <li>Reload the PLC program into the controller. (Possibly the command <b>Online→Reset (origin)</b> has been executed in DDS.)</li> </ul>
x240	ovrTrans Queue	"Free CAN objects" error	Overflow of the transmit request memory	<ul style="list-style-type: none"> <li>Reduce the number of transmit requests.</li> <li>Prolong the cycle time.</li> </ul>
x241	ovr Receive		Too many receive telegrams	Reduce the number of telegrams on the system bus (CAN).
x250	2.Flash Err	Error when the FLASH memory is accessed	The PLC program tries to access non-available or defect FLASH memory	Make sure that the PLC has the corresponding FLASH memory. If not, please contact Lenze. <b>After troubleshooting: Deenergise the device completely (disconnect 24 V supply, discharge DC bus)!</b>
x251	AddData CsErr	Error during FLASH memory access	Check sum error occurred when loading data into the FLASH memory	Check the checksum of the file to be loaded and repeat the data transfer.

Fault message		Description	Cause	Remedy
No.	Display			
x252	AddData DIErr	Error during FLASH memory access	An error occurred when downloading the data into the FLASH memory (e.g. time-out, transmission error, mains failure during transmission)	Check/repeat data transfer.
x260	Err Node Guard	"Life guarding event"	The controller configured as a CAN slave does not receive a "Node Guarding" telegram from the CAN master within the "Node Life Time".	<ul style="list-style-type: none"> <li>• Check wiring at X4.</li> <li>• Check CAN configuration.</li> <li>• Ensure that "node guarding" has been activated in the CAN master</li> <li>• Adapt the "node life time" (C0383) to CAN master setting.</li> </ul>

Explanation of the error numbers:  
 x 0 = TRIP, 1 = message, 2 = warning, 3 = FAIL-QSP  
 e.g. "2091": An external monitoring has triggered the warning EEr

### 4.3.2 Resetting system error messages

Reaction	Measures to reset the fault message
TRIP/ FAIL-QSP	 <b>Note!</b> If a TRIP/FAIL QSP source is still active, the pending TRIP/FAIL QSP cannot be reset.  The TRIP/FAIL QSP can be reset by: <ul style="list-style-type: none"> <li>• pressing ⇒ <b>STOP</b> on keypad XT EMZ9371 BC. Then, press <b>RUN</b> to re-enable the controller.</li> <li>• Set code C0043 = 0.</li> <li>• Control word C0135, bit 11</li> <li>• Control word AIF</li> <li>• Control word system bus (CAN) / MotionBus (CAN) at ECSxS/P/M</li> </ul> After the reset of the TRIP/FAIL QSP, the drive remains at standstill.
Message	 <b>Danger!</b> The fault message is reset automatically after the fault has been eliminated, and the drive restarts automatically.
Warning	After the fault has been eliminated, the fault message is reset automatically.



© 07/2013

Lenze Automation GmbH  
Hans-Lenze-Str. 1  
D-31855 Aerzen  
Germany



+49 (0)51 54 / 82-0



+49 (0)51 54 / 82 - 28 00



Lenze@Lenze.de



www.Lenze.com

Service

Lenze Service GmbH  
Breslauer Straße 3  
D-32699 Extertal  
Germany



00 80 00 / 24 4 68 77 (24 h helpline)



+49 (0)51 54 / 82-11 12



Service@Lenze.de



EDKVS93-01 ■ 13440647 ■ EN ■ 3.0 ■ TD06

10 9 8 7 6 5 4 3 2 1